



Note:

- 1/ Install Overflow 50mm higher than outlet
- 2/ Overflow to match outlet capacity.
- 3/ Overflow to be plumbed independent of stormwater, through soffit or exterior wall