



STEP

STEP 1. Viking Enviroclad behind cavity batten fully supported by substrate plywood or timber. Finish 150mm over & beyond the parapet junction

STEP 2. Wall Underlay behind cavity. Finish over membrane

STEP 3. *Saddle Flashing over cavity batten, directly behind cladding, refer Fig12 E2/AS1

STEP 4. Cladding to seal to saddle flashing

STEP 5. Metal Cap flashing to seal to saddle flashing

DRAWING TITLE

Viking WarmSpan - Enviroclad
Parapet_Timber wall ISO

NOTES:

- * Angle fillets are not required at upstands for Enviroclad
- * All fixings, cladding and structure are indicative only unless notated
- * All details to be read in conjunction with Viking Specifications

WarmSpan System is Branz
Appraised - 713

DRAWING

INFORMATION ONLY

Scale:	Date:	Drawn:	Viking
Not to Scale	01/03/2022		

Detail Ref
VIK_WSE_040A_PARAWALL