



'Z' = Variable according to wind zoning.  
Please refer to table 7 page 39 E2/AS1

Not to Scale	DATE 13/04/2017	Detail Ref:	ISSUE
DRAWN	Viking	EC04	A