


NOTE: How many vents?  
Refer Viking Technical Note Venting .

NOTE: Refer TOR\_004 for Direction of Plinth to watershed

NOTE:  
Ensure cross-ventilation within the roof structure  
E.G. use of a Castellated Batten directly under the Ply substrate or drill 20mm holes at top of timber supports

Viking 215mm high roof vent IMV111 with black dome, installed as per manufacturers instructions.

NOTE: Venting not required if specifying Viking WarmRoof or WarmSpan systems



NOTE:  
Substrate to comply with current Viking Roofspec Masterspec specification  
Substrate Checksheet available from [www.vikingroofspec.co.nz](http://www.vikingroofspec.co.nz)

DRAWING TITLE

Viking Torch-On  
Ventilation\_Cavity Vent

NOTES:

- Viking Waterproof Membrane as notated can be Viking Gemini, Lybra or Phoenix Super.
- All fixings, cladding and structure are indicative only unless notated.



Viking Torch-On systems are CodeMarked

DRAWING

INFORMATION ONLY

Scale:	Date:	Drawn:	Viking
Not to Scale	23/11/2020		

Detail Ref: **VIK\_TOR\_020\_VENTCAVI**

