

NOTE:
 Substrate to comply with current
 Viking Roofspec Masterspec
 specification
 Substrate Checksheet available
 from www.vikingroofspec.co.nz

Viking Enviroclad TPO
 waterproofing membrane 1.52
 mm thick, install as per
 manufacturers instructions


Viking 200x80mm TPO overflow
 scupper STP604, installed as per
 manufacturers instructions.

Viking Vapour Barrier, install as
 per manufacturers instructions

Viking PIR Polyiso Insulation

Substrate

Insulation to close off
 thermal break 300mm



'Z' = variable according to wind zone, please refer to table 7 E2/AS1

Viking Roofspec recommend that the membrane extends across the top of the parapet and down the front face of the cladding

The top of the parapet substrate, must be angled to allow water to run off the top of the parapet
 *If no metal cap is to be used, then a 10° slope to the top of parapet is required. Refer E2/AS1 6.5(a)

All fixings for the cap flashing, must be sealed and through the side of the flashing.

NOTE: Where Parapet meets wall refer WSE_40A

DRAWING TITLE

Viking WarmSpan - Enviroclad
 Parapet_with overflow

NOTES:

- * Angle fillets are not required at upstands for Enviroclad
- * All fixings, cladding and structure are indicative only unless notated
- * All details to be read in conjunction with Viking Specifications

WarmSpan System is Branz
 Appraised - 713

DRAWING

INFORMATION ONLY

Scale:	Date:	Drawn:	Viking
Not to Scale	01/03/2022		
Detail Ref: VIK_WSE_042_PARAOVER			